



P-Bath Fitting Instructions



Bathroom Suites Direct Fitting Instructions - P-Bath



1. Turn the bath upside to allow access to the base of the tub..



2. Place the longest cross bar onto the base of the bath at the widest end. Secure into the raised sections on the base of bath tub using the anchor brackets. Repeat step for other end of bath.



3. Attach the feet to the cross bar and secure using the washers and bolts.

Bathroom Suites Direct Fitting Instructions - P-Bath

4. turn the bath over so it is sat onto its feet and adjust the feet as required to ensure that the bath is completely level using a spirit level.



5. Place the bath as required and secure in place, attach the waste and overflow to the bath and plumb as needed.



6. Attach the clips to the panel(s) of the bath and offer to the bath.



7. using a small drill bit drill 3 holes along the bottom edge of the long side panel, and two in the end panel (if required).

*******IMPORTANT*******
** READ STEP 8 PRIOR TO DRILLING **

Bathroom Suites Direct Fitting Instructions - P-Bath



8. Secure the plastic anchor elbows to the side of the bath panel, lining them up with the cross bars, so their final position would be like the image.

when attaching the plastic elbows to the panels ensure that the position is correct prior to drilling.



Attach the two remaining bars to the base of the bath and to the elbows on the end panel (if required)

Prior to screwing the pieces together place the holding tabs for the decorative screw covers onto the thread of screw



9. Attach the side and end panel to the bath.